


Swivel iPad Clamshell Attachment




Side view



Landscape Mode



Portrait Mode



Optional Cover for Home Button

Foam Lining Removed

Home Button Shield

- 1) Remove foam lining from inside bottom of clam shell as shown.
- 2) Attach Home Button Shield with double-sided tape to inside of clam shell, keeping top of shield flush with clam shell opening as shown.

NOTE: This is a permanent fix and can't be easily removed.

SETUP INSTRUCTIONS